

AK4000适配相机参考

| 品牌 | 系列型号 | 可搭载镜头 | | |
|-------|--------------------|--|---|---|
| Canon | Canon 5DMarkIV | Canon EF 100mm f/2.8L IS USM+遮光罩 Canon EF 135mm f/2L USM+遮光罩 | Canon EF 85mm f/1.2 L II USM+遮光罩 Canon EF 50mm f/1.2L USM+遮光罩 | Canon EF 35mm f/2 IS USM+遮光罩 |
| | Canon 1D X Mark II | Canon EF 35mm f/2 IS USM+遮光罩 Canon EF 50mm f/1.2L USM+遮光罩* | Canon EF 85mm f/1.2 L II USM+遮光罩* Canon EF 135mm f/2L USM+遮光罩* | Canon EF 100mm f/2.8L IS USM微距+遮光罩* |
| | Canon 5DMarkIII | Canon EF 85mm f/1.2 L II USM+遮光罩 | Canon EF 24-105mm f/4L IS USM | |
| | Canon 6DMarkII | Canon EF 85mm f/1.2 L II USM+遮光罩 Canon EF 16-35mm f/2.8L II USM | Canon EF 24-105mm f/4L IS USM | Canon EF 50mm f/1.2L USM+遮光罩 |
| Nikon | Nikon D500 | NikonAF-S 105mm f/2.8G IF-ED VR | NikonNikkor 18-140mm f/3.5-5.6G ED VR | |
| | Nikon D7500 | NikonNikkor 18-140mm f/3.5-5.6G ED VR | NikonAF-S 105mm f/2.8G IF-ED VR | |
| Sony | Sony α9 | Sony E 50mm F1.8 Sony FE 35mm F1.4 | Sony E PZ 18-105mm F4 OSS Sony FE 24-240mm F3.5-6.3 | Sony FE 85mm F1.8 |
| | Sony α7R2 | SonyVario-Sonnar T* 24-70mm f/2.8 ZA SSM | | |
| | Sony α6500 | SonyFE 28-70mm f/3.5-5.6 OSS | | |
| | Sony α7R3 | Sony E 50mm F1.8 Sony FE 35mm F1.4 Sony FE 12-24mm f/4.0 G | Sony E PZ 18-105mm F4 OSS Sony FE 24-240mm F3.5-6.3 | Sony FE 85mm F1.8 Sony FE 24-105mm f/4 G OSS |

*温馨提示:相机需紧靠俯仰电机。本表格会随固件发布实时更新,未列入表中的相机型号,后续会根据市场反馈进行适配。具体适配相机请咨询客服。